

MOUNTING


Grinder must be bolted to a bench or B&D pedestal #53536 for optimum use —

EXHAUST PORTS

Unit equipped with ports to facilitate connection to a dust removal system.

EXTRA EQUIPMENT

1. Buffing wheels
2. Wire brushes
3. Eye shields — (requires drilling out hole on top of guard for mounting).
4. Wheel dressers



Black & Decker®

POWER TOOLS

FACTORY SALES and SERVICE CENTERS

IMPORTANT!

To assure product SAFETY and RELIABILITY, repairs, maintenance and adjustments should be performed by BLACK & DECKER Service Centers or other qualified service organizations, always using BLACK & DECKER replacement parts.

	Area Code	Telephone No.		Area Code	Telephone No.
ALABAMA: Birmingham 35233, 1717 Third Ave., South.	205	324-6691	NEW MEXICO: Albuquerque 87110,		
ARIZONA: Phoenix 85004, 537 E. McDowell Rd.	602	AL 8-1332	4700 Lomas Blvd. N.E.	505	265-6401
ARKANSAS: Little Rock 72201, 519 West Seventh St.	501	FR 2-3040	NEW YORK: Buffalo 14209, 881 W. Delaware Ave.	716	TT 4-6220
CALIFORNIA: Anaheim 92802, 1235 So. Euclid Ave.	714	772-4050	New York 10462, 1894 E. Tremont Avenue (Bronx).	212	SY 2-2700
Los Angeles 90007, 2432 S. Broadway.	213	RI 9-0371	New York 10014, 227 Varick St. (Manhattan).	212	WA 9-6450
Oakland 94606, 1107 E. 14th St.	415	TE 4-5944	New York 11377, 56-15 Queens Blvd. (Woodside).	212	DE 5-1042
Sacramento 95814, 1915 Seventeenth St.	916	444-3188	Rochester 14620, 476 Clinton Ave. S.	716	454-3814
San Diego 92105, 3811 El Cajon Blvd.	714	280-3331	Syracuse 13224, 2140 Erie Blvd. E.	315	446-3086
Santa Clara 95050, 2291 The Alameda.	408	241-9162	NORTH CAROLINA: Charlotte 28206, 1710 N. Graham St.	704	FR 5-3721
South San Francisco 94080, 1139 Airport Blvd.	415	871-7278	Fayetteville 28306, P.O. Box 4305, Highway 301, S.	919	425-1181
Van Nuys 91401, 14920 Victory Blvd.	213	787-5531	Greensboro 27403, 1008 W. Lee St.	919	275-0906
COLORADO: Denver 80204, 675 Kalamath St.	303	222-0621	OHIO: Cincinnati 45203, 1225 Western Ave.	513	421-2275
CONNECTICUT: Hartford 06114, 131 Meadow St.	203	249-6241	Cleveland 44113, 3901 Detroit Ave.	216	OL 1-4243
FLORIDA: Jacksonville 32208, 5224 Pearl St.	904	356-2951	Columbus 43202, 3975 East Livingston Ave.	614	237-0461
Miami 33168, 13345 N.W. Seventh Ave.	305	681-6658	Dayton 45420, 617 Watervliet St.	513	252-1821
Orlando 32806, 940 So. Orange Ave.	305	423-1651	Solon 44139, 6225 Cochran Rd.	216	CH 5-5330
Tampa 33609, 3401 W. Kennedy Blvd.	813	872-8317	Toledo 43606, 2629 W. Central Ave.	419	475-6771
GEORGIA: Atlanta 30313, 316 Techwood Drive, N.W.	404	JA 4-0431	OKLAHOMA: Oklahoma City 73106, 1318 Linwood Blvd.	405	CE 2-7515
HAWAII: Honolulu 96813, 675 Auahi St.	808	536-9374	Tulsa 74145, 3120 South Sheridan Rd.	918	622-5666
ILLINOIS: Chicago 60607, 1100 W. Jackson Blvd.	312	TA 9-3500	OREGON: Portland 97209, 1640 N. W. Johnson St.	503	CA 8-8631
Chicago 60646, Lincolnwood, 6710 N. Crawford Ave.	312	OR 3-0923	PENNSYLVANIA: Harrisburg 17112,		
Chicago 60643, 10708 S. Western Ave. (Beverly Hills).	312	BE 3-6832	6070 Allentown Blvd.	717	545-0651
Rock Island 61201, 725 30th St.	309	788-1744	Lancaster 17604, 715 Fountain Ave.	717	393-5831
INDIANA: Evansville 47708, 931 Bond St.	812	425-4269	Philadelphia 19103, 333 No. 20th St.	215	LO 4-5520
Indianapolis 46202, 1125 W. 16th St.	317	632-5569	Pittsburgh 15232, 5437 Baum Blvd.	412	362-2700
IOWA: Des Moines 50312, 2811 Ingersoll Ave.	515	CH 4-7257	RHODE ISLAND: E. Providence 02914,		
KANSAS: Wichita 67214, 203 N. Mathewson St.	316	263-6571	2777 Pawtucket Ave.	401	434-1655
KENTUCKY: Louisville 40209, 4407 Park Blvd.	502	366-1495	SOUTH CAROLINA: Greenville 29601, 407 Pendleton St.	803	232-3038
LOUISIANA: New Orleans 70002,			TENNESSEE: Knoxville 37917, 1123 North Central St.	615	546-2481
3310 N. Causeway Blvd. (Metairie).	504	837-2550	Memphis 38116, 986 East Brooks Rd.	901	332-3444
MARYLAND: Baltimore 21211, 203 West 28th St.	301	HO 7-7411	Nashville 37203, 601 Eighth Ave., South	615	254-1061
Baltimore 21205, 4712 Erdman Ave.	301	485-5550	TEXAS: Amarillo 79106, 3308 West 6th Ave.	806	DR 3-1531
Bladensburg 20710, 4501 Baltimore Ave.	301	779-3808	Dallas 75207, 1808 N. Industrial Blvd.	214	RI 1-6401
Towson 21204, 701 E. Joppa Rd.	301	828-2910	Fort Worth 76103, 1801 Bomar St.	817	336-0175
MASSACHUSETTS: Boston 02135,			Houston 77003, 105 Sampson St.	713	228-7521
12 Market St. (Brighton).	617	ST 2-6264	San Antonio 78210, 1111 S. Pensa St.	512	LE 4-4611
MICHIGAN: Detroit 48219, 18133 W. McNichols Rd.	313	534-8880	UTAH: Salt Lake City 84115, 1541 S. Second West	801	HU 6-7056
Detroit 48234, 11360 East Seven Mile Rd. (Mt. Elliott).	313	527-5010	VIRGINIA: Falls Church 22046, 129 Annandale Rd.	703	533-1147
Grand Rapids 49509, 3662 Clyde Park Ave., S.W.	616	534-7708	Norfolk 23517, 337 W. 21st St.	703	627-4521
MINNESOTA: Minneapolis 55408, 2815 Nicollet Ave.	612	823-5283	Richmond 23222, 1424 Chamberlayne Ave.	703	649-9245
MISSOURI: Kansas City 64108, 2705 McGee Trafficway.	816	HA 1-1493	WASHINGTON: Seattle 98109, 701 Third Ave., N.	206	AT 2-6432
St. Louis 63110, 615 S. Vandeventer Ave.	314	JE 3-2210	Spokane 99207, 3550 N. Market St.	509	HU 9-9164
NEBRASKA: Omaha 68102, 2218 Leavenworth St.	402	345-2330	WEST VIRGINIA: Charleston 25312, 1638 Sixth Ave.	304	343-0289
NEW JERSEY: Newark 07104, 868 Broadway.	201	HU 3-1076	WISCONSIN: Milwaukee 53213, 6301 Blue Mound Rd.	414	476-7800

BLACK & DECKER MFG. CO., Limited, Canada		
BROCKVILLE, ONTARIO	Perth Street	MONTREAL 10, P. Q.
CALGARY, ALBERTA	1003 11th Avenue, S. W.	7865 St. Lawrence Blvd.
DON MILLS (Toronto)	2 Valleybrook Drive	OTTAWA, ONTARIO
EDMONTON, ALBERTA	11440 Ave.—142 Street	418 Laurier Avenue, West
HALIFAX, NOVA SCOTIA	803 McLean Street	QUEBEC CITY, P. Q.
HAMILTON, ONTARIO	180 Parkdale Ave., N.	330 St. Roch Street
LONDON, ONTARIO	631 Commissioners Rd., East	REGINA, SASKATCHEWAN
		1076 Albert Street
		SASKATOON, SASK.
		Diamond Ind. Center, Quebec & 33rd St.
		VANCOUVER 10, B. C.
		24 West 2nd Ave.
		WINNIPEG 10, MANITOBA
		934 St. James St.

ALABAMA, Montgomery
ALASKA, Anchorage
Fairbanks
ARIZONA, Tucson
CALIFORNIA, Fresno
Stockton

CONNECTICUT, New Haven
DELAWARE, Wilmington
FLORIDA, Pensacola
IDAHO, Boise, Lewiston

AUTHORIZED SERVICE STATIONS
MAINE, Westbrook
MISSISSIPPI, Jackson
NEVADA, Reno, Las Vegas
NEW YORK, Schenectady

OHIO, Youngstown
PENNSYLVANIA, Allentown
Erie
SOUTH CAROLINA, Charleston
SOUTH DAKOTA, Rapid City

TEXAS, Corpus Christi
El Paso
VIRGINIA, Roanoke
WASHINGTON, Yakima
WEST VIRGINIA, Wheeling

Guarantee Black & Decker guarantees, for one year from date of purchase, to correct by repair or parts replacement without charge any defect due to faulty material or workmanship. Simply return the complete unit, transportation prepaid, to any Black & Decker Service Center or Authorized Service Station. Naturally, we assume no responsibility for damage caused by misuse, careless handling or where repairs have been made or attempted by others. No other guarantee, written or verbal, is authorized by us.

OWNER'S MANUAL

This booklet is provided for your convenience in the Use & Care of your new Black & Decker Bench Grinder. These instructions include Safety Precautions, Operation, Preventive Maintenance, Maintenance and other pertinent data to assist you in assuring long life and dependable service from your Bench Grinder.

CAT. NOS. 4330, 4330-01, 4335 — TYPE 1

10" HEAVY-DUTY BENCH GRINDER

Bulletin 2928-1

THE BLACK & DECKER MFG. CO. — TOWSON, MARYLAND 21204, U.S.A.



1. **KNOW YOUR POWER TOOL.** Read the owner's manual carefully. Learn its application and limitation, as well as the specific potential hazards peculiar to this tool.
2. **KEEP GUARDS IN PLACE** and in working order.
3. **GROUND ALL TOOLS.** If tool is equipped with three-prong plug, it should be plugged into a three-hole electrical receptacle. If an adapter is used to accommodate a two-prong receptacle, the adapter wire must be attached to a **known ground**. **Never** remove the third prong.
4. **REMOVE ADJUSTING KEYS AND WRENCHES.** Form habit of checking to see that keys and adjusting wrenches are removed before turning on tool.
5. **KEEP WORK AREA CLEAN.** Cluttered areas and benches invite accidents.
6. **AVOID DANGEROUS ENVIRONMENT.** Don't use power tools in damp or wet locations. Keep your work area well illuminated.
7. **KEEP CHILDREN AWAY.** All visitors should be kept a safe distance from work area.
8. **MAKE WORKSHOP KIDPROOF**—with padlocks, master switches, or by removing starter keys.
9. **DON'T FORCE TOOL.** It will do the job better and be safer at the rate for which it was designed.
10. **USE RIGHT TOOL.** Don't force tool or attachment to do a job it was not designed for.
11. **WEAR PROPER APPAREL.** No loose clothing or jewelry to get caught in moving parts.
12. **USE SAFETY GLASSES.** Also use face or dust mask if cutting operation is dusty.
13. **SECURE WORK.** Use clamps or a vise to hold work, when practical. It's safer than using your hand, frees both hands to operate tool.
14. **DON'T OVERREACH.** Keep your proper footing and balance at all times.
15. **MAINTAIN TOOLS IN TOP CONDITION.** Keep tools sharp and clean for best and safest performance. Follow instructions for lubricating and changing accessories.
16. **DISCONNECT TOOLS** before servicing and when changing accessories such as blades, bits, cutters.
17. **USE RECOMMENDED ACCESSORIES.** Consult owner's manual. Use of improper accessories may be hazardous.
18. **AVOID ACCIDENTAL STARTING.** Make sure switch is off before plugging in cord.

1. Always wear safety glasses or other eye protection when operating this tool, and eye shields, mounted on the wheel guards, are strongly recommended.
2. Replace a cracked wheel immediately. Handle grinding wheels carefully to avoid bumping or dropping. DO NOT use a grinding wheel that has been dropped. Before using, inspect each grinding wheel for cracks or flaws and if these are evident, discard the wheel.

These units are equipped with an outlet box mounted on the back of the unit for permanent wiring, as required by Underwriters Laboratories. Wiring diagrams are pasted to the underside of the base. To insure proper wiring & "grounding" of tool, have connection made by a qualified electrician.

This tool is equipped with lubricant sealed ball bearings which require no further lubrication for the life of the bearing.

Four pole capacitor start induction motor. Squirrel cage rotor.

Cat. No.	Phase	HP	Cycles	Rated @ 115 V.	RPM No Load	Voltage, A.C.
4330	1	1	50/60	14.6/13	1500/1800	115 Volts
4330-01	1	1	50/60	14.6/13	1500/1800	220 Volts
4335	3	1	50/60	14.6/13	1500/1800	220/440 Reconnectable

Remove 4 screws holding wheel guard cover. Loosen and remove hexagon nut. (Nut on left wheel has left hand threads, nut on right wheel has right hand threads) and clamp washer. Remove wheel. To reassemble, reverse above steps. Do not overtighten nut. Wheel size 10" O.D., 3/4" I.D., 1" Width.

No. 34575 One Shatter-Proof Eye Shield . . . Fastens permanently to Bench Grinder. Adjusts quickly to various positions to suit operator. Not illuminated. (Replacement glass, No. 34576).

No. 19115 Cutter Wheel Dresser . . . Has spare set of cutter wheels. Dresses wheels quickly for fast grinding.

No. 21961 Diamond Dresser . . . Produces an accurate, smooth face for finish grinding.

No. 53536 Pedestal . . . Holds grinder at convenient height. Has detachable water pot. Height: 31 $\frac{5}{8}$ "; Base: 16 square.

Grinding Wheels (10" Diam. x 1" Face x 3/4" Hole):

No. 10274 Specification A24Q6V, Type 1

No. 10275 Specification A46N6V, Type 1

Wire Wheel Brushes (10" Diam. x 1 7/8" Face x 3/4" Hole:

No. 21407 .014 Wire Diam. (30 Gage)
No. 23012 .0118 Wire Diam. (33 Gage)

Cotton Buffing Wheels (10" Diameter x 3/4" Hole)

Cotton Buffing Wheels
No. 26873 5 1/2" Wide

No. 26873 $\frac{5}{8}$ " Wide
No. 26876 $\frac{1}{4}$ " Wide


CAUTION: Recommended accessories for your Bench Grinder are listed above. The use of any other accessory might be more hazardous.

3. Before mounting a new wheel, be sure that it is marked with an R.P.M. that is the same as, or higher than, the no-load speed of the grinder as marked on the nameplate. Do not overtighten wheel nut. Use only flanges furnished with this grinder.
4. Never start a grinder with anyone, including the operator, standing in line with the wheel. After installing a replacement wheel, stand to one side and allow it to revolve freely for about one minute.
5. Do not grind on the sides of grinding wheels unless they are the special wheels designed specifically for this purpose.
6. Use of any other accessory or attachment other than those specified might create a hazard for the operator.

Cat. No. 4330, TY. 1, 115V, 1 Ph.

Cat. No. 4330-01, TY. 1, 220V, 1 Ph.

Cat. No. 4335, TY. 1, 220/440V, 3 Ph.

[illegible]